


ENYA

Shower


INSTALLATION MANUAL
PRODUCT CARE & MAINTENANCE
WARRANTY GIUIDE




INSTALLATION MANUAL

3 Door Installation pg 3

2 Door Installation pg 7



3 SIDED SHOWER INSTALLATION GUIDE



COMPONENTS


- A - Door Assembly
- B - Door Wall Receiver
- C - Cover Trim x 2 (On Selected Models)

TOOLS REQUIRED

- Drill
- Spirit level
- Tape Measure
- Screw Driver (No.1 Sq drive)
- Caulking Gun
- Masking tape
- Pencil
- Cleaning Cloth

(For shipping purposes the Door & Return Receivers are packed in the sides of the Door and Return)


INSTALLATION COMPONENTS



Handle (where applicable)




Tube of NG Silicone



Drip Seal -1m



No.6 x 38mm screw
Qty 6



Cleaning Towelette (White showers only)



Screw Cap
Qty 6





No.6 x 10m Screw



9mm Plug
Qty 3


NOTE

Your shower Door can be installed to open from the left or right hand side by rotating the door 180 degrees, and the Return Panel can be fitted on either side. You must decide which way the door is to open before starting the installation.




1 Determine which side the Door is to be hung. Position one of the Door Wall Receivers hard against the inside edge of the tray upstand. If installing on to a tray without front upstands place the Wall Receiver 10mm in from the front edge of the tray.


NOTE: If the shower walls are to be tiled the Wall Receivers must be installed to the Water proof membrane before tiling. This ensures the doors will fit within the lip of the tray.



2 Plumb up the Door Wall Receiver using a spirit level. Mark the position with a pencil line.




3 Pre drill three equally spaced clearance holes (i.e. top, bottom and centre) in the Door & Return Wall Receivers using a 4.5mm drill bit. Reposition the Wall Receivers to the pencil line on the wall. Drill into the wall through the clearance holes using the 3.0mm drill bit. **N.B.** The holes preferably locate into a stud or nog. As an alternative, a toggler system can also be used.




4 Fix the Wall Receivers to the walls using the No.6 x 38mm stainless steel screws

N.B. As an extra precaution seal holes with silicone.





5 Fit the handle to the door (where required). This will assist in the opening & closing during the installation process.

Ensure to fit the plastic washers and bush to prevent metal on glass contact.



6 Slide the remaining Door Wall Receiver onto the Door Assembly.

7



Ensure the Door is facing the correct way with the door opening outwards. Do not remove the door setting block, this will assist in supporting the door during installation and setting the correct clearance from the sill.


Lift the Door assembly with the Wall Receiver attached onto the shower step and slide into the Door Wall Receiver already installed.

8



Plumb the Door and remaining Wall Receiver. Through the oversize holes in the Door jamb drill through the Wall Receiver frame and into the wall stud using a 3.0 mm drill bit.

9



Fix the Wall Receiver to the wall using the No.6x 38mm stainless steel screws.

10




Fill the oversize holes in the door Jamb using the 9mm plastic plugs.

11




From the inside using a 3.0mm drill bit; drill through the vertical sections of the Door into the Wall Receivers. Fix the Door to the Wall Receivers. You must have a minimum of 10mm overlay and the holes must be drilled no more than 5mm from the edge of the vertical aluminium sections. Fix in place using the 6.

12




Fix in place using the 6 gauge x 10mm screws.

13



Cover all Screw heads with the Screw Caps


All Screw fixings are made from inside the shower



14


Slide the outside Clamp Block Covers off the Pivot Clamp. Using a flat blade screwdriver, adjust the door as required, by loosening the screws on each pivot block.

Once the door adjustment is complete ensure the screws are retightened and reinstall the Clamp Block Covers. Open the door and remove the door setting block.



15


Fit the Drip Seal. The Drip seal is supplied in a 1m length, this will need to be cut to the desired lengths for each side of the pivot. The opening side Drip seal will also need to be notched to fit under the door magnet profile. Make the Notch 13mm in length and finishing down to the horizontal ledge of the drip seal.



16

Fit the Drip Seals to the glass door.


SEALING THE SHOWER



17

For White Showers only - take the Cleaning Towelette and wipe the surfaces of the Powder coated profiles where Silicone will be applied. Allow to dry (1-2 minutes).

IMPORTANT: DO NOT apply sealant to the inside of the shower




18

The Door can now be sealed in place using silicone sealant. Ensure all surfaces are first cleaned with dry clean cloth. Seal between the tray upstand and the door set along the bottom outside edges. Seal vertically between the Wall Receivers and Wall Liner.

Note: MASKING the area to be Sealed will give you a superior finish.


COVER TRIM



19

The Cover Trim is provided to cover the exposed vertical edge of the wall liner and is the final step of the installation. For some installations the Cover trims may require cutting to length. To fit the Cover trim apply small vertical beads of silicone down the Wall Receiver and the exposed wall lining outside of the Wall Receiver. Embed the Cover trim into the silicone. If the liner extends more than 10mm it will need to be trimmed prior to fitting the Cover Trim.

2 SIDED SHOWER INSTALLATION GUIDE



COMPONENTS


- A - Door Assembly
- B - Door Wall Receiver
- C - Return Wall Receiver
- D - Return Assembly
- E - Cover Trim x 2 (On Selected Models)

TOOLS REQUIRED

- Drill
- Spirit level
- Tape Measure
- Screw Driver (No.1 Sq drive)
- Caulking Gun
- Masking tape
- Pencil
- Cleaning Cloth

(For shipping purposes the Door & Return Receivers are packed in the sides of the Door and Return)


INSTALLATION COMPONENTS



Handle (where applicable)




Tube of NG Silicone




Drip Seal -1m



No.6 x 38mm screw
Qty 6




Cleaning Towelette (White showers only)



Screw No.6 x
Cap 10m Screw
Qty 12 Qty 9


NOTE

Your shower Door can be installed to open from the left or right hand side by rotating the door 180 degrees, and the Return Panel can be fitted on either side. You must decide which way the door is to open before starting the installation.




NOTE: If the shower walls are to be tiled the Wall Receivers must be installed to the Water proof membrane before tiling. This ensures the doors will fit within the lip of the tray.


Before commencing: Partially remove the clear protective film from the edges of the wall liner where the Wall receivers will be fitted. Pre drill three equally spaced clearance holes (i.e. top, bottom and centre) in the Door & Return Wall Receivers using a 4.0mm drill bit.




1 Determine which side the Door is to be hung. Position the Door Wall Receiver hard against the inside edge of the tray upstand. If installing on to a tray without front upstands place the Wall Receiver 10mm in from the front edge of the tray.




2 Ensure the Door Wall receiver is plumb.




3 Drill into the wall through the clearance holes using a 3.0mm drill bit. N.B. The holes preferably locate into a stud or nog. As an alternative, a toggle system can also be used.



4 Apply Silicone sealant to each of the holes. Fix the Wall Receivers to the walls using the No.6 x 38mm stainless steel screws. Repeat on adjacent side for the Return Wall Receiver.




5 Fit the handle to the door (where required). This will assist in the opening & closing during the installation process. Ensure to fit the plastic washers and bush to prevent metal on glass contact.




6 Ensure the Door is facing the correct way with the door opening outwards. Do not remove the door setting block, this will assist in supporting the door during installation and setting the correct clearance off the sill.

DOOR


RETURN




7 A Return Sill is supplied with the Return panel and is only temporarily clipped to one end of the panel. As the Return panel can be installed left or right hand it is necessary to remove the sill, apply sealant and attach to the correct end of the Return panel.




8 Apply a small continuous bead of NG Silicone sealant into the bottom of the Return sill channel. Do not fill the channel with silicone as this will be excessive and the majority will ooze out making cleanup difficult.



9 Fit the Return Sill to the lower edge of the Return Panel. Carefully wipe away any excess silicone that may ooze out




10 Position the Return Panel into the Return Wall Receiver ensuring the Corner Post engages over the door jamb section, do not fix in place at this time.




11 For Sureseal trays the Door and Return panels should be close to the inside edge of the tray's upstand as possible.

For other applications, check that the doors are parallel with the front edge of the tray.



12 Ensure that each section is square to the shower base and plumb.


SECURE THE DOOR SET *(All screw fixings are made from the inside)*




13 From the inside using a 3.0mm drill bit; drill through the vertical sections of the Door and Return into the Wall Receivers. Fix the Door and Return Panel to the Wall Receivers. You must have a minimum of 10mm overlay and the holes must be drilled no less than 5mm from the edge of the vertical aluminium sections. Secure in place using the 6 gauge x 10mm screws.



14 Using the 3.0mm drill bit, drill through the corner section and into the aluminium frame. (Use the "V" groove line as a guide) Secure in place using the 6 gauge x 10mm screws.



Cover all Screw heads with the Screw Caps.




ADJUST THE DOOR

Slide the outside Clamp Block Cover off the Pivot Clamp. Using a Phillips head screwdriver sufficiently loosen the two screws, adjust the door by sliding left or right in the pivot.


Once the door adjustment is complete ensure the screws are retightened and reinstall the Clamp Block Covers. Open the door and remove the door setting block.

DRIP SEALS




The Drip seal is supplied in a 1m length, this will need to be cut to the desired lengths for each side of the pivot. The opening side Drip seal will also need to be notched to fit under the door magnet profile. Make the Notch 13mm in length and finishing down to the horizontal ledge of the drip seal.

NOTE: The flexible vertical blade will face towards the inside of the shower.




Fit the Drip Seals to the glass door.

SEALING THE SHOWER



For White Showers only - take the Cleaning Towelette and wipe the surfaces of the Powder coated profiles and shower tray where Silicone will be applied Allow to dry (1-2 minutes).




The Door and Return can now be sealed in place using silicone sealant. Ensure all surfaces are first cleaned with dry clean cloth. Seal between the tray upstand and the door set along the bottom outside edges. Seal vertically between the Wall Receivers and Wall Liner.

Note: MASKING the area to be Sealed will result in a superior finish.

IMPORTANT: DO NOT apply sealant to the inside of the shower

COVER TRIM




The Cover Trim is provided to cover the exposed vertical edge of the wall liner and is the final step of the installation. For some installations the Cover trims may require cutting to length.

To fit the Cover trim apply small vertical beads of silicone down the Wall Receiver and the exposed wall lining outside of the Wall Receiver. Embed the Cover trim into the silicone. If the liner extends more than 10mm it will need to be trimmed prior to fitting the Cover Trim.

Your Shower is now complete. Allow the Sealants to cure for a minimum of 24 hours.



PRODUCT CARE & MAINTENANCE



PRODUCT MAINTENANCE

As the bathroom can be a high use zone in the house, it is important to understand how to maintain products. Below are our suggestions on how to clean and care for them.

- Wipe down the shower or use a plastic squeegee to remove excess water from the glass after use
- Use a trusted glass cleaner on shower glass. If your glass has been treated with Diamond Fusion, please go to www.diamondfusion.co.nz/product-instructions/ for cleaning instructions
- Use Vibrance Surface Cleaner to clean the tray and wall liner
- Waste lid and cup should be removed and cleaned regularly
- Drips seals can be removed for cleaning and can simply be replaced when they no longer look their best

VIBRANCE SURFACE POLISH AND CLEANER

Suitable for use on Acrylic, Vitreous China, Porcelain, Tiled and Solid Surfaces

Step 1: use ShowerMaster Vibrance Surface Cleaner for daily cleaning


Step 2: use ShowerMaster Vibrance Surface Polish to restore lustre, remove light scuff marks and leave a protective film.

Developed and manufactured in New Zealand specifically for Athena bathroomware.

Note: Before using on other products it should be tested on an inconspicuous area.



WARRANTY GUIDE



ENYA WARRANTS THE PRODUCT AGAINST ANY MANUFACTURING FAULTS FOR DOMESTIC AND LIGHT COMMERCIAL INSTALLATIONS (FOR EXAMPLE, APARTMENTS AND REST HOMES) AS FOLLOWS:

PRODUCT CATEGORY		WARRANTY PERIOD
Showers	Door set, acrylic wall liner, shower tray and EasyClean Waste body	10 years
Showers	Drip strips, vertical seals and waste lids	1 Year

CONSUMER GUARANTEES ACT 1993 (“CGA”)

The warranty referred to in this booklet do not limit or affect your rights and remedies under the CGA. The manufacturers’ warranties are in addition to your rights and remedies under the CGA. For further information on your rights and remedies under the CGA please go to consumerprotection.govt.nz.

PRODUCT WARRANTY

We stand behind our products and offer warranties on all our bathroomware so that you have peace of mind that what you have purchased for your home is of the highest quality and fits the purpose for which it was designed.

- The product must be installed according to the instructions supplied.
- The supply water temperature at the tap must not exceed 50°C.
- Commercial applications - 12 month warranty on all products.
- 10 year warranties are effective from November 2024.

WHAT TO DO SHOULD A PROBLEM ARISE

In the first instance, please contact the merchant from which you purchased the product. You will need your proof of purchase from the merchant to assist you with your warranty claim or claim under the CGA. Your claim will be assessed in a timely manner by your local Harrison Bloy representative.

HARRISON / BLOY

BATHROOMS • KITCHENS • PLUMBING